




**Product Name: NIMROD S**

## General information

- This luminaire must be installed in accordance with the latest edition of the IET Wiring Regulations and local Building Regulation by a qualified competent person.
- The mains power supply must be turned off before inspection, installation or removal of the luminaire, ensuring that the supply is locked off to prevent inadvertently switching the supply on.
- It is the installer's responsibility to ensure that the installation is suitable for the total load of the luminaire(s). The supply cable fuses/circuit breakers must be correctly rated for the electrical load and taking into account for any transient inrush currents that may occur.
- It is the installer's responsibility to ensure that the environmental operating and storage conditions are complied with and that any fire risks are considered.
- Do not perform insulation strength or insulation resistance tests on the installation with the luminaire(s) connected, this can damage the luminaires and give erroneous readings.
- Do not loop-in supply cables at the luminaire supply terminals unless there is provision for 2-way connection at the terminals.
- The light source contained in this luminaire must only be replaced by TamLite Lighting or an appointed service agent.
- Emergency lighting luminaires must be installed and maintained in accordance with the emergency lighting standard BS 5266-1.
- To ensure that the product warranty remains valid, the luminaire must be installed and maintained in accordance with these installation instructions and the product must not be modified in any way.

- Luminaires marked with this symbol must not be covered with thermally insulating material.
- This symbol on covers over light sources indicates dangerous live parts do not operate the luminaire with this cover removed.

## Dimensions



Product Name: NIMROD S

|  |  |
|--|--|
| <p><b>1</b></p> <p>Remove the product from its packaging.</p>                                    | <p><b>2</b></p> <p>Remove the two screws which hold the diffuser in place.</p>     |
| <p><b>3</b></p> <p>Unscrew LED board screw and remove the LED board from the luminaire body.</p> | <p><b>4</b></p> <p>Bring supply cable in to luminaire body.</p>                    |
| <p><b>5</b></p> <p>Attach luminaire body to mounting surface.</p>                                | <p><b>6</b></p> <p>Terminations shown for standard and standard DALI variants.</p> |
| <p><b>7</b></p> <p>Terminations shown for emergency and emergency DALI variants.</p>             | <p><b>8</b></p> <p>Replace the gear tray and diffuser.</p>                         |

Page 2 of 2

Tamlite Technical  
 Stafford Park 12,  
 Telford, Shropshire,  
 TF3 3BJ

+44(0)1952 292441  
 technical@tamllite.co.uk  
 Document No: V2

|  |  |  |                     |  |      |      |       |   |
|--|--|--|---------------------|--|------|------|-------|---|
|  |  |  | 220-240V<br>50/60Hz |  | IP65 | IK08 | TP(a) | ta<br>0°C to 25°C<br>5°C to 25°C<br>for M3 variants |
|--|--|--|---------------------|--|------|------|-------|---|